

TONER TIPS

How to change toner on
Kyocera TASKalfa Series

1. When your black toner is empty, pull it out. It now becomes your waste toner bottle.



2. Rotate it 180 degrees, so the grey tab is facing up.



3. Pull out the existing waste toner bottle




4. Smoothly insert your new waste toner bottle (empty black) until it clicks. Grey tab facing up!



IMPORTANT NOTES

1. Always replace your waste toner when you replace the black toner; stored waste toner bottles can be accidentally thrown away or forgotten about.
2. Your previous/full waste toner should be thrown away.
3. Empty color toner bottles are #2 recyclable.
4. Toner doors will not open until completely empty.



SCAN FOR VIDEO

All toner bottles should enter the machine as smoothly as they come out. Incorrectly inserted toner can cause severe damage to your machine!

